



Technical resources

Production type stirred ball mill

Model: JM

<https://www.tencanballmills.com/en/products/grinding-series/stirring-ball-mill/production-type-stirred-ball-mill.html>

09.10.2026 / TENCAN

Production type stirred ball mill

Model: JM

Production-type stirred ball mill for ultra-fine grinding of zirconium silicate, alumina, ceramics, chemicals, paints, battery materials. High efficiency, continuous operation for industrial mineral processing.

Technical specifications

Volume	1~600L
Loading capacity	0.35~200L
Output particle size	≤1μm

These specifications describe the series. Confirm the selected model, power supply and configuration before ordering.



The production-type stirred mill is mainly composed of a stationary grinding barrel filled with small-diameter grinding media, a stirring device and other auxiliary devices (such as: circulation device, cooling device, timing, speed control, etc.). It has high grinding efficiency and small crushing particle size. It can well achieve various process parameter requirements and simulate various indicators in production. At the same time, due to its advantages of small batch, low power consumption, and low price, it is an optional equipment for schools, research units, and companies to conduct research on crushing processes, new materials, and coatings. It is widely used in the production of various ultrafine powders such as zirconium silicate, zirconium oxide, alumina, ceramics, chemicals, electronic materials, magnetic materials, papermaking, coatings, non-metallic minerals, new materials, paints, graphite, calcium carbonate, pharmaceuticals, etc.

研磨系列

搅拌球磨机/细节



精选材质



效率高



抗磨损



噪音低



自动升降

搅拌杆可自动升降，磨桶可自由
翻转

温度控制

球磨筒带有夹套，可以很好的控
制研磨温度



特殊定制

可以根据需要制作带有各种特殊
功能的设备，如：定时、调速、
循环、调温等。

研磨系列

搅拌球磨机/产品用途

广泛应用于硅酸锆、氧化锆、氧化铝、陶瓷、化工、电子材料、磁性材料、造纸、涂料、非金属矿、新型材料、油漆、石墨、碳酸钙、制药等多种细磨粉体的生产领域。



制药



食品



化工



锰酸锂

研磨系列

搅拌球磨机/研磨效果



研磨前



研磨后



Technical parameters

model	Overall dimensions (mm)	Frequency conversion speed (r/min)	Equipment weight (KG)	Loading capacity (L)	Motor power (KW)	Grinding barrel material (material thickness)	Grinding barrel size (without water jacket)	Grinding barrel size (with water jacket)
JM-100L without lift	1100X910X1900	0~145	590	35	7.5	Stainless steel, carbon steel (about 6mm)	To be determined	Φ540*600
						Zirconia, corundum (about 10mm)	To be determined	Φ560*620
						PTFE, nylon (about 15mm)	To be determined	To be determined
						Polyurethane (approx. 15mm)	Φ496*620	Φ560*620
JM-200L without lift	1400X1060X2200	0~145	790	70	11	Stainless steel, carbon steel (about 6mm)	To be determined	Φ640*830
						Zirconia, corundum (about 25mm)	To be determined	Φ695*850
						PTFE, nylon (about 15mm)	To be determined	To be determined
						Polyurethane (approx. 15mm)	Φ600*830	To be determined
JM-300L without lift	1800X1200X2600	0~110	970	100	15	Stainless steel, carbon steel (about 5mm)	To be determined	Φ710*890
						Zirconia, corundum (about 25mm)	Φ740*890	Φ800*890
						PTFE, nylon (about 20mm)	To be determined	To be determined
						Polyurethane (about 20mm)	To be determined	Φ750*894

JM-500L without lift	2750X1400X3340	0~90	1730	170	18.5	Stainless steel, carbon steel (about 10mm)	Φ820*1010	Φ916*1010
						Zirconia, corundum (about 25mm)	To be determined	Φ960*1022
						PTFE, nylon (about 20mm)	To be determined	To be determined
						Polyurethane (about 20mm)	To be determined	Φ940*1022

* JM-100L/200L discharge valve 1.5 inches, JM-300L/500L discharge valve 2 inches;

* JM-100L/200L/300L/500L feed particle size $\leq 20\text{mm}$;

* JM-100L can be equipped with an optional delivery pump (feeding particle size $\leq 2.5\text{mm}$), JM-200L/300L can be equipped with a delivery pump (feeding particle size $\leq 4.5\text{mm}$), and JM-500L can be equipped with a delivery pump (feeding particle size $\leq 8\text{mm}$).

The spindle drives the mixer to rotate at high speed, causing the grinding medium to move irregularly. This chaotic and disordered movement will cause collision, extrusion, friction and shearing of the grinding medium, thereby crushing and finely grinding the material. In addition, the size, shape and proportion of the grinding media are different, and the grinding effects obtained are also different. Generally speaking, the larger the size of the grinding media, the coarser the material will be crushed. On the contrary, the smaller the grinding media, the finer the material is ground. The appropriate ratio of different specifications of grinding media, coupled with the appropriate adjustment of the speed, will result in better grinding effects.

1. The energy utilization rate is high and high power density can be obtained, so it saves energy.
2. The product particle size is easy to adjust, and the fineness can be ensured by adjusting the residence time of the material in the cylinder.
3. Small vibration and low noise.
4. Beautiful appearance, high-end atmosphere, excellent performance, simple maintenance, easy and labor-saving operation, and durable.
5. The mixing rod can be raised and lowered automatically, and the grinding barrel can be flipped freely.
6. It can well realize various process requirements and can carry out continuous or intermittent production as needed.
7. Since the ball mill barrel is equipped with a jacket, the grinding temperature can be well controlled.

8. Equipment with various special functions can be made as needed, such as: timing, speed adjustment, circulation, temperature adjustment, etc.
9. You can choose grinding barrels and stirring devices made of different materials (stainless steel, corundum ceramics, polyurethane, zirconia, etc.).

Contact

Changsha Tianchuang Powder Technology Co., Ltd. / Changsha, Hunan, China

Email: lichang0516@gmail.com

Phone / WhatsApp: +86 731 84027560 / WhatsApp +86 19021571516

<https://www.tencanballmills.com/en/products/grinding-series/stirring-ball-mill/production-type-stirred-ball-mill.html>

Before operation, review the selected model's instructions and the material requirements.